MAXTEK

# Bluetooth Headphones

**MODEL NUMBER: 61339**

## USER GUIDE

**After Sales Support**

UK/N.IRELAND HELPLINE Nº: 01270 508538
REP.IRELAND HELPLINE Nº: 1800 995 036
WEBSITE: www.quesh.co.uk
EMAIL: enquiries@quesh.co.uk

3 YEAR WARRANTY

# Contents

1. Welcome Section

2. General Information & Safety Instructions

3. Contents & Features

4. Controls

5. Setup

6. Charging & Indicators

6. Care & Maintenance

7. Specifications

**After Sales Support**

UK/N.IRELAND HELPLINE Nº: 01270 508538
REP.IRELAND HELPLINE Nº: 1800 995 036
WEBSITE: www.quesh.co.uk
EMAIL: enquiries@quesh.co.uk

# Welcome Section

Congratulations!

You have made an excellent choice with the purchase of this quality MAXTEK® product.

By doing so you now have the assurance and peace of mind which comes from purchasing a product that has been manufactured to the highest standards of performance and saftey, supported by the high quality standards of Quesh Ltd.

We want you to be compeletly satisfied with your purchase so this MAXTEK® product is backed by a comprehensive manufacturer's 3 year warranty and outstanding after sales service through our dedicated helpline.

We hope you enjoy using this product for many years to come.

If you require technical support or in the unlikely event that your purchase is faulty, please telephone our helpline for immediate assistance. Faulty product claims made within the 3 year warranty period will be repaired or replaced free of charge provided that you have a satisfactory proof of purchase (keep your receipt safe). This does not affect your statutory rights. However be aware that the warranty will become null and void if the product is found to have been deliberately damaged, misused and/or disassembled.

**After Sales Support**

UK/N.IRELAND HELPLINE Nº: 01270 508538
REP.IRELAND HELPLINE Nº: 1800 995 036
WEBSITE: www.quesh.co.uk
EMAIL: enquiries@quesh.co.uk

3 YEAR WARRANTY

# General information & Safety Instructions

Rechargeable Polymer Li-ion battery 320mAH battery inside headphones.

Do not dispose of batteries in your household waste.

Please contact your local authority for details on safe disposal.



- Never throw batteries into a fire or expose to excessive heat sources.
- If batteries are swallowed, please seek mmediate medical attention.
- Always ensure correct +/- battery polarity when installing batteries.
- Do not recharge non-rechargeable batteries.

Equipment, which is marked with the WEEE logo
(as shown on the left), should not be thrown away with your household waste. Contact your local authority waste disposal department, as they will be able to provide details of the recycling options available in your area.



Electrical and electronic equipment (WEEE) contains materials, parts and substances, which can be dangerous to the environment and harmful to human health if the waste of electrical and electronic equipment (WEEE) is not disposed of correctly.

Equipment, which is marked with the WEEE logo
(as shown on the left), should not be thrown away with your household waste. Contact your local authority waste disposal department, as they will be able to provide details of the recycling options available in your area.

**After Sales Support**

UK/N.IRELAND HELPLINE Nº: 01270 508538
REP.IRELAND HELPLINE Nº: 1800 995 036
WEBSITE: www.quesh.co.uk
EMAIL: enquiries@quesh.co.uk

# Contents & Features

## Contents

1 x Bluetooth Headset
1 x USB charge cable

## Features

- Hands free compatible
- Battery life displayed on Apple iOS devices
- Can connect two bluetooth devices simultaneously
- Voice prompt
- Auto switch between music and calls
- In-built omnidirectional microphone
- Adjustable headband
- Rechargeable Polymer Li-ion battery
- 10m bluetooth range

**After Sales Support**
UK/N.IRELAND HELPLINE Nº: 01270 508538
REP.IRELAND HELPLINE Nº: 1800 995 036
WEBSITE: www.quesh.co.uk
EMAIL: enquiries@quesh.co.uk

# Controls

**Bluetooth Headphones**

1. Adjustable headband
2. > Next track (press and hold to fast forward)
3. < Previous track (press and hold to rewind)
4. LED indicator
5. ⏻ On/Off, answer/end call, voice dial, redial last number, play/pause
6. + Volume up
7. - Volume down
8. Built-in Microphone

**After Sales Support**
UK/N.IRELAND HELPLINE Nº: 01270 508538
REP.IRELAND HELPLINE Nº: 1800 995 036
WEBSITE: www.quesh.co.uk
EMAIL: enquiries@quesh.co.uk

# Setup

**Turning on and pairing**
Press and hold the ⏻ button for 3 seconds to power up.
Continue to hold the ⏻ button for another 6 seconds to enter bluetooth pairing mode. The LED light will flash red and blue whilst in this mode and you will hear a voice prompt saying “Pairing”.

On the device you want to pair the headphones to, please go to your bluetooth settings and search for the device “MAXTEK AUDIO”. Once selected to pair with your device you will hear a voice prompt saying “Pairing complete”.

If the pairing is unsuccessful, please turn the headset off and on to enter pairing mode.

*Please note:*
This headset will automatically pair with the last connected device.

**How to accept/end calls**
You can use this headset to make and receive calls. When you’re receiving an incoming call, the music will automatically pause. Press the ⏻ button to answer the call. Your voice will be picked up by the microphone. To end the call press the ⏻ button.

To reject a call press and hold the ⏻ button for 1 second.

To voice dial, if your mobile phone supports this function, press and hold the ⏻ button for 1 second till you hear the indication sound and the use your voice command to dial. Otherwise dial the number on your mobile phone as normal and interface with the headset.

To redial the last number press the ⏻ button quickly twice.

**After Sales Support**
UK/N.IRELAND HELPLINE Nº: 01270 508538
REP.IRELAND HELPLINE Nº: 1800 995 036
WEBSITE: www.quesh.co.uk
EMAIL: enquiries@quesh.co.uk

# Charging & Indicators

**Charging the headphones**

Plug the micro USB cable into the charge port. It take approximately 4 hours to fully charge. When the battery is full, the LED light tuns blue. Only charge the headphone when they are turned off.

*Please note:*

On the first time charging the battery, please ensure the battery has been fully charged before use.

**LED indicators**

| | |
|---|---|
| LED off | Power off |
| LED blue | Power on |
| LED flashing blue/red | Pairing mode |
| LED red | Low battery |
| LED flashing red | Battery almost drained |
| LED flashing blue | Battery recharging |

# Care & Maintenance

**Headphones Maintenance**

- Re-charge your headset once every three months when it is not in use to keep the battery in good condition.
- If you do not use the headset for a long time. You have to charge the battery for 30 minutes and the Red LED lights up.
- Do not wash the headset with harsh chemicals, soaps or detergents
- For extended storage, first fully charge the battery till the LED turns blue.
- This product is not waterproof.
- Do not store the headset in high temperature environments including intense sunlight heat or naked flames.

**After Sales Support**
UK/N.IRELAND HELPLINE Nº: 01270 508538
REP.IRELAND HELPLINE Nº: 1800 995 036
WEBSITE: www.quesh.co.uk
EMAIL: enquiries@quesh.co.uk

# Specification

## Bluetooth Headphones

- Bluetooth V3.0+EDR
- Bluetooth profiles: A2DP, AVRCP, HSP, HFP
- 10m operating range
- Omni directional headphones
- Frequency responce: 20Hz-20KHz
- 320mAH rechargeable polymer Li-ion battery
- Power input: DC5V
- Charge time: Approximately 4 hours
- Battery duration approximately 12 hours

**After Sales Support**

UK/N.IRELAND HELPLINE Nº: 01270 508538
REP.IRELAND HELPLINE Nº: 1800 995 036
WEBSITE: www.quesh.co.uk
EMAIL: enquiries@quesh.co.uk

# Warranty Certificate

## Warranty
This product is guaranteed to be free from defects in workmanship and parts for a period of 36 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion, solely at our option with no charge for parts and labour. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product the consumer has under existing U.K. laws.

## Proof of Purchase
This warranty is valid for the original purchase and is not transferable.
Please keep your purchase receipt as proof of purchase and as proof of the date of when the purchase was made. The receipt must be presented with the warranty card when making a claim under this warranty.

## Service during the Warranty Period
Please ensure the product is properly packaged so as to ensure that no damage occurs in transit. Also make sure that you have included a detailed explanation of the problem.

## Extent of the Warranty
This warranty is limited to defects in workmanship or parts. All defective products or parts will be repaired or replaced. This warranty does not extend to accessories.

## Normal Wear and Tear
This warranty does not cover normal wear and tear of the product or parts.

## Exclusions
This warranty does not cover the following:
- Any defect caused by accident, misuse, abuse, improper installation or operation, lack or reasonable care, unauthorised modification, loss of parts, tampering or attempted repair by a person not authorised by the distributor.
- Any product that has been damaged by lightning strike either directly or indirectly, or on a main's or vehicle outlet power surge or liquid ingress.
- Any product that has not been installed, operated or maintained in accordance with the manufacturer's operating instructions provided with the product.
- Any product that has been used for purposes other than domestic use.
- The product if it is located outside of the U.K. and Ireland
- Any damage caused by improper power input or improper cable connection.

**After Sales Support**

UK/N.IRELAND HELPLINE N$^{O}$: 01270 508538
REP.IRELAND HELPLINE N$^{O}$: 1800 995 036
WEBSITE: www.quesh.co.uk
EMAIL: enquiries@quesh.co.uk

3 YEAR WARRANTY

# Warranty Card

## Bluetooth Headphones

**Model Number: 61339**

Please keep your purchase receipt together with your warranty card

Name: _____

Address: _____

_____

_____

☎ _____

Date of purchase: _____

Location of purchase: _____

**Fault Description:**

We recommend that you attach a photocopy of your receipt, showing the date of purchase, to this warranty card and keep it for your reference. In the event of a product fault, please call the After Sales Support team. Please ensure that you have the product details (as shown on this card) to hand so that the support team are able to respond as quickly and efficiently as possible.

**After Sales Support**

UK/N.IRELAND HELPLINE Nº: 01270 508538
REP.IRELAND HELPLINE Nº: 1800 995 036
WEBSITE: www.quesh.co.uk
EMAIL: enquiries@quesh.co.uk

**Service Helpline**

QUESH LTD,
1 SOLWAY COURT,
CREWE BUSINESS PARK,
CW1 6LD

3 YEAR WARRANTY